





SORTER SYSTEMS



Crossbelt Sorter



Shoe Sorter




Split Tray Sorter



Slide Tray Sorter



Roll-on Sorter



Switch / Divert Sorter



Narrow Belt Sorter



LR Sorter

LODAMASTER HQ

Orta Mahalle Ordu Sokak
No:23 A Blok Kat:8 İzPark
Kartal - İstanbul, Türkiye
E-mail: info@lodamaster.com
Office: +90 216 305 05 07

ARGEVI

Zümrütevler Mh. Ural Sk.
No:14 Kat:2
Maltepe - İstanbul, Türkiye
E-mail: info@argevi.com
Office: +90 216 353 60 10

LODAMASTER TECHNIC

İnönü Mah. Gebze Plastikçiler OSB
9.Cad No:3 41400,
Gebze - Kocaeli, Türkiye
E-mail: info@lodamaster.com
Office: +90 262 502 18 09

LODAMASTER EUROPE

Håndværkervej 26, DK-6270,
Tønder - Danmark
E-mail: europe@lodamaster.com
Office: +45 2910 2776

LODAMASTER POLAND

Ul. Loteryjki 71, 01-937,
Warszawa - Polska
E-mail: info.pl@lodamaster.com
Office: +48 571 025 775



LOADING & UNLOADING

As an official partner of Joloda BV, we offer automatic loading and unloading systems that cut the time gap between unloading a truck and delivering materials to the production starting point. We integrate docking stations into the process flow, instead of treating them as a separate operation.

Our automatic and manual Container Systems enable us to load and unload container trucks in a matter of minutes. Using them is much more efficient than transferring pallets and other forms of cargo one at a time with a forklift.



The Authorized Distributor